

INSTRUCTIONS

1. Start by peeling the film off of the sticky pad on the Scorpion.



2. *Then, before installing, use supplied blue security key to unlock axle. Unlock by turning counter clockwise. Align left side of phone in Scorpion



4. Using supplied blue security key, turn clockwise to lock axle.



6. Press the lock in to secure. Scorpion should now be locked into place.



3. Adjust Scorpion until leg is snug against device, using supplied blue security key, turn clockwise to tighten.
*Note: Do not over-tighten



5. Place installed device in base.

