

INSTRUCTIONS

Tel: 855-757-2776
scorpionsp.com
support@scorpionsp.com
August 2022

***IMPORTANT* PLEASE READ BEFORE INSTALLING**

Before installing, use supplied blue key to unlock Scorpion axle. Unlock by turning counter clockwise.



1. Insert the blue key into the axle of the Scorpion (green dot side) and rotate counter-clockwise to expand the legs wide enough for the device fits into the Scorpion.



2. Remove the 3M adhesive covering.



3. Place the device into the Scorpion and ensure that the leveling plate is aligned in the center of the device.



4. Press firmly on the front of the device to ensure the dual lock and leveling plate fully adheres to the device.



5. Tighten the side legs of the Scorpion until they slightly touch the side of the device by inserting the blue key into the axle (green dot side) and rotate clockwise.



NOTE: Do not over tighten

6. Raise the leveling plate by inserting the blue key into the leveling plate studs. Switch back and fourth between the studs to ensure equal pressure.



NOTE: 3 turns and switch until plate is raised

7. After Securing leveling plate, go back and tighten side legs. There will no longer be a gap between the screen and legs when leveling plate has been properly raised.



***IMPORTANT* MUST LOCK AXLE TO FULLY SECURE**

8. To lock axle, insert the blue key into the center of the Scorpion Body located on the back side of the device. Turn the blue key clockwise to tighten the screw and lock the axle into place.



9. Feed the charging cable through before attaching Scorpion to the base.



10. Place the installed device into the receiver. Press the lock in to secure. Scorpion should now be locked into place.



IMPORTANT

Do not over tighten the leveling plate. If you see a bump or bubble in the screen, or bend in the device, the leveling plates are over tightened. Please refrain from over tightening as this may damage the device.